



**GHO Disconnect Box**

- 1 GHO Disconnect Box
- 2 Bearing 3/4
- 3 Brake Solenoid
- 4 Ground Screw #8-32 x 3/8
- 5 Washer SAE #8
- 6 GHO aux. brake release connector
- 7 Cotter Pin 3/32 x 1
- 8 GHO Brake Release Lever
- 9 Track Bolt 1/4-20
- 10 Hex Nut 1/4-20
- 11 Fiber Washer
- 12 Hoist Switch
- 13 Machine Screw #6-32 X 1
- 14 Lock Nut #6-32
- 15 Tapping Screw #8-32 x 3/4